

# MISS SCARLET

LONG LASTING LIP INK

020.C2



ISO 16128



## OVERVIEW

Do you need a very long-lasting color on your lips without any greasy or sticky feeling ? This lip ink will be your ally ! The smooth texture is obtained thanks to SAFIC' Care T CI, and the color will stain your lips whole day long. Oligo-HA is an aging protector, the answer for moisturizing and wrinkle improvement. Simply apply on the lips (be careful not to overfill...) and let it dry to get the final look.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	86,70
	Glycerin		Glycerin	Humectant	2,50
B	SAFIC' Care T CI	SAFIC-ALCAN	Chondrus Crispus	Thickener	2,00
C	Sensicare® C 3000	CHEMIPOL*	Dehydroacetic Acid, Benzyl Alcohol	Preservative	0,90
	Blackberry Cream Balm F86050L	RAVETLLAT*	Parfum	Fragrance	0,15
D	Demineralized water	/	Aqua	/	2,00
	Ponceau 4R 80% E124 (656813)		SYMRISE*	CI 16255	Color
E	Demineralized water	/	Aqua	/	4,00
	Glycerin		Glycerin	Humectant	0,50
	Oligo-HA		HYUNDAI BIOLAND*	Hyaluronic Acid	Active
F	SAFIC' Care A CLFE	SAFIC-ALCAN	Aqua, Butylene Glycol, Citrus Limon Fruit Extract	1,00	

\* Please contact us to know in which country we are supplier of

SAFIC' Care is a trademark of SAFIC-ALCAN

## PROCESS

PHASE A : Heat up to 75° C under stirring.

PHASE B : Pre-mix then add it to phase A and stir for 15 minutes at 75° C until homogeneous. Allow to cool to room temperature.

PHASE C : Add to phase AB and stir until homogeneous.

PHASE D : Stir until dissolved then add it to phase ABC and homogenize.

PHASE E : Pre-mix Oligo-HA + Glycerin then add it to water of phase E and stir until dissolved. Add it to phase ABCD and homogenize.

PHASE F : Add to phase ABCDE and homogenize.

Complement in water, homogenize and adjust pH to 5,5-6,0.

## PROPERTIES

APPEARANCE : Red transparent gel.

VISCOSITY : 38 300 cPs (Brookfield RVDV-I+, 5 rpm, 1 min, spindle 5).

pH : 5,5 - 6,0.