

PRIME'N'ROSES

SERUM 2-IN-1 PRIMER

98%

Ingredients of natural origin**

ISO 16128



FORMULA

Boundaries between skincare and makeup are blurred with **PRIME'N'ROSES** that **moisturises**, **unifies complexion** and **prepares skin for make-up**. Formulated with very **low molecular weight hyaluronic acid** and an **anti-aging rice bran oil**, this serum 2-in-1 primer boosts **skin radiance** and brings an **immediate healthy glow**. Infused with **rose water**, this **light and fluid emulsion** provides a **powdery and silken finish**. Thanks to its **sebum absorbing power**, **PRIME'N'ROSES** enhances make-up long wear.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	62,48
	Rosa BioPhytWater	GREENPHYT*	Rosa Damascena Flower Water, Citric Acid, Sodium Benzoate, Potassium Sorbate	Hydrolat	15,00
	SymDiol® 68 green	SYMRISE*	1,2-Hexanediol, Caprylyl Glycol	Multifunctional (Emollient, Moisturizer, Preservative Booster)	1,00
	SymSave® H	SYMRISE*	Hydroxyacetophenone		0,50
B	Oligo-HA	SOCHIBIOS / HYUNDAI-BIOLAND*	Hyaluronic Acid	Active	0,20
	Butylene Glycol	/	Butylene Glycol	Humectant	5,00
	Gum Acacia Quick Gum Type 8287 RD	NOREVO*	Acacia Senegal Gum	Film Former	0,30
C	Structure® XL	NOURYON*	Hydroxypropyl Starch Phosphate	Thickener	4,20
D	Harmonie™ Soft fluid	MOMENTIVE*	C9-12 Alkane	Emollient	3,00
	Sabosoft NSIL MB	SABO*	Caprylic/Capric Triglyceride, Oryza Sativa Bran Oil, Tocotrienols	Emollient	3,00
	Sabowax P6OL	SABO*	Olive Oil Polyglyceryl-6 Esters	Emulsifier	1,00
E	Apricot 52881	RAVETLLAT*	Parfum	Fragrance	0,20
F	Shiconix Liquid MD (J)	ICHIMARU PHARCOS*	Octyldodecyl Myristate, Lithospermum Officinale Root Extract	Natural coloring agent	0,125
G	ImerCare® Matte	IMERYS*	Kaolin	Mattifying Agent	1,00
	Sumicair™ Naturefeel 43031	SUDARSHAN*	Mica, Phytelphas Aequatorialis Seed Powder	Sensory Agent	1,00
	Tapioca Pure	NOURYON*	Tapioca Starch	Absorbing powder	2,00

* Please contact us to know in which country we are supplier of.
SAFIC' Care is a trademark of SAFIC-ALCAN

PRIME'N'ROSES

SÉRUM 2-EN-1 PREMIER

98%

Ingredients of natural origin

ISO 16128



PROCESS

PHASE A : Weigh and mix ingredients from phase A. Heat up to 45°C in order to dissolve SymSave® H.

PHASE B : Pre-mix ingredients from phase B and add to phase A.

PHASE C : Add Structure® XL. A gel forms gradually.

PHASE D : Pre-mix and heat up to 45°C ingredients from phase D in order to fluidify the mixture. Start emulsification under high stirring (2000 rpm) during 45 minutes then cool down under medium stirring.

PHASE E, F et G : Gradually add ingredients from phases E, F and G. Adjust the pH if necessary.