

# SILVER LUMINESCENCE

MOISTURIZING SERUM

008(2).K26

GP2024OTHERS

99,5%

of natural origin  
ingredients

ISO 16128



## OVERVIEW

This fluid face serum has a pleasing aesthetic thanks to Sumicos™ Flash Silver (HG155) suspended with the action of SAFIC' Care T XG Clear P. The innovative association of Velsan® Flex and Velsan® CGE enables to preserve the formula while keeping it clear. This serum contains high effectiveness active ingredients such as MossCellTec™ Aloe with its impact on decreasing wrinkles and Lipobelle™ Pino C with its hydrating and soothing properties. The neurocosmetic active ingredient TiMood™ adds to this formula a positive impact on emotional well-being for a cocooning selfcare experience.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	83,35
B	Glycerin		Glycerin	Humectant	2,00
	SAFIC' Care T XG Clear P	SAFIC-ALCAN	Xanthan Gum	Suspensive agent	0,40
C	A-Leen® 5	MINASOLVE*	Pentylene Glycol	Solubilizer	5,00
	Velsan® Flex	CLARIANT*	Capryloyl/Caproyl Anhydro Methyl Glucamide, Aqua	Preservative booster	3,00
	Velsan® CGE		Caprylyl Glyceryl Ether		0,50
	Sun Nordic Amber SO044966	SOZIO*	Parfum	Fragrance	0,30
D	TiMood™	MIBELLE BIOCHEMISTRY*	Zanthoxylum Alatum Fruit Extract, Glycerin, Pentylene Glycol, Aqua	Active	2,00
	MossCellTec™ Aloe		Xylitol, Caprylyl Glycol, Ketoglutaric Acid, Aqua		2,00
	Lipobelle™ Pino C		Pinus Cembra Wood Extract, Cannabis Sativa Seed Oil, Cannabis Sativa Leaf Extract, Lecithin, Alcohol, Pentylene Glycol, Tocopherol, Aqua		0,40
E	Glycerin	/	Glycerin	Humectant	1,00
	Sumicos™ Flash Silver (HG155)	SUDARSHAN*	Mica, CI 77891	Effect Pigment	0,05

\* Please contact us to know in which country we are supplier of

SAFIC' Care is a trademark of SAFIC-ALCAN

## PROCESS

PHASE A : Place under stirring.

PHASE B : Pre-mix then add it to phase A and stir for 15 minutes until homogeneous.

PHASE C : Pre-mix with magnetic stirring for 30 minutes then add it to phase AB and homogenize.

PHASE D : Pre-mix then add it to phase ABC and homogenize.

PHASE E : Pre-mix then add it to phase ABCD and homogenize.

Adjust pH to 5,5-6,0.



## PROPERTIES

APPEARANCE : Clear serum with silver pearls.

VISCOSITY : 3 392 cPs  
(Brookfield RVDV-I+, 5 rpm, 1 min, spindle 2).

pH : 5,5 - 6,0.

